



C-Bus DSI Gateway

Installation Instructions

5508DSIP Series




Table of Contents

| | | |
|------|---|----|
| 1.0 | Product Range | 3 |
| 2.0 | Description | 3 |
| 3.0 | Capabilities | 3 |
| 4.0 | Compatible Loads | 3 |
| 5.0 | Wiring Instructions | 3 |
| 6.0 | C-Bus DSI Gateway Features | 4 |
| 6.1 | Local Override Buttons | 4 |
| 6.2 | Remote Override Facility | 4 |
| 6.3 | Network Burden | 5 |
| 6.4 | Channel Overload or Short Circuit Detection | 5 |
| 6.5 | Channel Faulty Lamp/Ballast Detection | 5 |
| 6.6 | Power Fail Recovery Options | 5 |
| 7.0 | Priority of Operating Modes | 5 |
| 8.0 | Indicators | 6 |
| 8.1 | C-Bus Indicators | 6 |
| 8.2 | Unit Indicator | 6 |
| 8.3 | Channel Indicator | 6 |
| 9.0 | Power-up Load Status | 7 |
| 10.0 | C-Bus Power Requirements | 7 |
| 11.0 | Stand-alone Programming | 7 |
| 12.0 | C-Bus Network Connection | 7 |
| 13.0 | Programming Requirements | 9 |
| 14.0 | Power Surges and Short Circuit Conditions | 9 |
| 15.0 | Megger Testing | 9 |
| 16.0 | Important Warning | 9 |
| 17.0 | Standards Complied | 9 |
| 18.0 | Product Specifications | 10 |
| 19.0 | Mechanical Specifications | 11 |
| 20.0 | Technical Support and Troubleshooting | 11 |

Copyright Notice

© 2001 Copyright Clipsal Integrated Systems Pty Ltd. All rights reserved.

Trademarks

- Clipsal is a registered trademark of Gerard Industries Pty Ltd
- C-Bus is a registered trademark of Clipsal Integrated Systems Pty Ltd
- Intelligent Building Series is a registered trademark of Clipsal Integrated Systems Pty Ltd

All other logos and trademarks are the property of their respective owners.

Disclaimer

Clipsal Integrated Systems Pty Ltd reserves the right to change specifications or designs described in this manual without notice and without obligation.

1. Product Range

- 5508DSIP** C-Bus Eight Channel DSI Gateway (220-240V, 50-60Hz)
- E5508TDSIP** C-Bus Eight Channel DSI Gateway (110-120V, 50-60Hz)

2. Description

The C-Bus DSI Gateway is a C-Bus output device, designed to control TRIDONIC® DSI Dimming ballasts or equivalent products. For ease of installation the 5508DSIP range is DIN mounted, measuring 12M wide (1M=17.5 +0.5/-0.0mm). Eight independent channels are provided for general DSI dimming control applications. Remote access to diagnostic information is available for all fittings via software tools.


3.0 Capabilities

This DSI Gateway provides two C-Bus connections through the use of RJ45 connectors, allowing similar units to be quickly looped together. In normal operation, where the DSI Gateway is connected to the mains, the unit draws no power from the C-Bus network. If the DSI Gateway is disconnected from the mains, the unit will draw 18mA from the C-Bus network. The DSI Gateway is capable of generating C-Bus clock signals. Together with the C-Bus power supply, it provides all the support necessary for a simple C-Bus network. Local toggle buttons are provided to allow individual DSI channels to be toggled at each unit as well as via C-Bus commands.

4.0 Compatible Loads

The C-Bus DSI Gateway is designed to supply 200mA per channel, which can control up to 100 TRIDONIC® DSI dimming ballasts or equivalent products

5.0 Wiring Instructions



* For 5508DSIP use 240V~, 50/60Hz and for E5508TDSIP use 110V~, 50/60Hz

Notes:

1. A maximum of 100 C-Bus DSI Gateway units can be connected to a single C-Bus network.
2. The installer must fix mains cabling in the distribution board using cable ties or trunking as required by local cabling rules. Care must be taken not to allow copper strands to enter DIN unit apertures.
3. Mains connections to the unit are internally isolated. The two mains supplies may be wired from different voltage phases, but DO NOT CROSS NEUTRAL CONNECTIONS.

Note: Rubber bungs are supplied (3 off) for unused RJ45 connectors, to stop foreign bodies from entering the unit.

6.0 C-Bus DSI Gateway Features

6.1 Local Override Buttons


The buttons located on the front of the unit provide a means to toggle each channel locally. Each button is illuminated when the respective channel is in the ON state.

| Operation | Function |
|---|--|
| Short Press | Toggle |
| Double Click (two short presses within 2 seconds) | Returns this channel only to the C-Bus network level |
| Long Press (a press longer than 2 seconds on any local override button) | Returns ALL channels to C-Bus network level |

Note: Double Click and Long Press operations will only occur if the unit/channel is already in override mode. By default C-Bus commands received by the unit will override local toggle changes. In this case only the channels associated with the received commands will revert to the current C-Bus network state. This option may be disabled via installation software. Please refer to Section 7, Priority of Operating Modes.

6.2 Remote Override Facility

Remote control of all channels on a unit can be achieved via the extra pairs of conductors on the C-Bus connector. C-Bus is a balanced network, therefore at any point where C-Bus negative (-) is taken, C-Bus positive (+) must also be present. Hence both network conductors must be looped through all remote input switches on the network. The diagram below shows how switches may be connected in parallel on any one network, using the green and green/white conductors for a remote ON function. Brown and brown/white may be wired in the same fashion for remote OFF, with these conductors being connected to C-Bus negative (-) via the switch to action state. A Clipsal 30/1/2LM mechanism makes an ideal remote input switch.



6.3 Network Burden

The DSI Gateway incorporates a software selectable Network Burden. This Burden may or may not be required in order to ensure correct operation of the C-Bus Network. To enable the on-board Burden, set the Unit Address to 001.

6.4 Channel Overload or Short Circuit Detection

Channel overload occurs when the terminals of the channel are shorted or the connected load draws more than 200mA. In such cases the DSI Gateway will shut down the channel and the corresponding channel LED indicator flashes at approximately 8 times per second.

6.5 Channel Faulty Lamp/Ballast Detection

The DSI Gateway is also capable of detecting faulty lamps connected to its terminals.

When this occurs, the DSI Gateway will shut down the channel and the corresponding channel LED indicator flashes at a slower rate of approximately 4 times per second.

6.6 Power Fail Recovery Options

In the event both the C-Bus Network voltage and the Mains Supply (C-Bus) fail (or are disconnected) the DSI Gateway has three software selectable output recovery options (per channel). When either the C-Bus Network voltage or the Mains Supply (C-Bus) is restored, each channel will recover to one of the following three options:

- 1) Brightness of the load prior to power interruption is retained, or
- 2) The load is set full on (100% brightness), or
- 3) The load is turned off (0% brightness)

If the Mains Supply (DSI Gateway) fails (or is disconnected) the loads will continue under the control of their DSI ballasts and remain at levels set before the power interruption.

7.0 Priority of Operating Modes

The output status of the C-Bus DSI Gateway can be changed by pressing a C-Bus Key, by activating any of the Local Override buttons or by using the Remote Override facilities. The table below shows the priority ranking of these control inputs.

| Mode | Priority | Function |
|-------------------------------------|--------------|------------------------|
| Remote OFF | 1 | Turns all channels OFF |
| Remote ON | 2 | Turns all channels On |
| Local Override | 3 * | Toggles the channel |
| C-Bus Input Unit (key, PIR etc.) | 4 * (Lowest) | Controls the channel |

* Local Override has priority over normal C-Bus commands received on the bus (such as those generated by pressing a C-Bus Key). By default, if any channel is in Local Override mode and a C-Bus command is received for that channel, the C-Bus command state will be imposed ("Enable C-Bus Priority" option). This feature can be disabled in software such that all relevant C-Bus commands will be ignored by the unit whilst in Local Override Mode. For further information relating to the programming of DIN Rail 5508DSIP/ E5508TDSIP units, please refer to the C-Bus Manual (or C-Bus Manual Addendum V211A:C-Bus DIN and PRO Series).

8.0 Indicators

8.1 C-Bus Indicators

This indicator shows the status of the C-Bus Network at this unit. If sufficient network voltage and a valid C-Bus clock signal are present the "OK" signal will be displayed (continuous green light). If a network is connected which demands more current than the power supplies can support, this indicator will flash showing marginal network voltage. If there is no C-Bus clock present the indicator will not light. When the unit is powered from C-Bus only for stand-alone programming this indicator will not function.

| Indicator Status | Meaning |
|------------------|--|
| On | C-Bus network operational |
| Flashing | Insufficient power to support network |
| Off | No C-Bus clock present; No mains connection |

Further debugging of possible network problems can be achieved with the Clipsal C-Bus Network Analyser Tool CAT. No. 5100NA.

8.2 Unit Indicator

This indicator shows the status of the individual unit. A Continuous Green light (OK) indicates the mains power is connected. If the indicator is flashing with a 90% On duty cycle, it means any one of the eight channels have been toggled (using the override facility) into a state different to the C-Bus network. This applies to either Local or Remote Override inputs. This indicator will not function when the unit is powered from C-Bus only for stand-alone programming.

| Status | Meaning |
|----------|--------------------------|
| On | Normal Operation |
| Flashing | Unit in override mode |
| Off | No mains power connected |

8.3 Channel Indicator

These indicators show the status of the individual DSI channels.

A steady "ON" Green Light (channel LED) indicates the channel is operating normally and is set to a level above zero dimming. Steady "OFF" indicates the channel is operating normally and is set to zero dimming level.

A slow flashing indicator (approx. 4Hz), indicates the corresponding DSI channel has a faulty DSI ballast connected to its terminals.

A fast flashing indicator (approx. 8Hz) indicates the corresponding DSI channel is overloaded (>200mA) or it's terminals may be shorted.

| Indicator Status | Meaning |
|------------------------|--|
| On | Normal Operation with non-zero DSI dimming level |
| Off | Normal Operation with zero DSI dimming level |
| Flashing @ 8Hz approx. | Overload or terminal shorted |
| Flashing @ 4Hz approx. | Faulty lamp or ballast |

9.0 Power-up Load Status

All C-bus units have onboard non-volatile memory, which is used to store the operating state of the unit in case of mains power loss. On restoration of power the DSI Gateway initiates a short power-up diagnostic routine which runs for approximately 5 seconds. Following the diagnostic routine the eight channels will assume levels set by the user programmable option in software (see Section 6.6 "Power Fail Recovery Options"). For further information relating to the programming of the DIN Rail 5508DSIP/E5508TDSIP units, please refer to the C-Bus Manual (or the C-Bus Manual Addendum V211A: C-Bus DIN and PRO Series).

10.0 C-Bus Power Requirements

In normal operation, where the DSI Gateway is connected to the mains (C-Bus), the unit draws no power from the C-Bus network.

If the mains supply (C-Bus) is disconnected, the unit will draw 18mA from the C-Bus network.


11.0 Stand-alone Programming

A 5508DSIP/E5508TDSIP series product can be programmed without a mains power connection, by connecting the unit to an operational C-Bus network capable of supporting at least one additional C-Bus device (18mA of current required). Once the unit is connected to a network, it can be configured using C-Bus Installation software. Indicators will not function until mains is connected.


12.0 C-Bus Network Connection

It is recommended Category 5 data cable is used, Clipsal catalogue number 5005C305B. Installation of the 5508DSIP products requires connection to the unshielded twisted pair C-Bus Network Cable. This connection is polarity sensitive and clearly shown on the following page.

A Clipsal Cat 5 UTP patch cord is included with the unit for easy interconnection. Up to 100 x DSI Gateway units can be connected to the C-Bus network.



| RJ Pin | C-Bus Connection | Colour |
|--------|------------------|--------------|
| 1 | Remote ON | Green/White |
| 2 | Remote ON | Green |
| 3 | C-Bus Neg (-) | Orange/White |
| 4 | C-Bus Pos (+) | Blue |
| 5 | C-Bus Neg (-) | Blue/White |
| 6 | C-Bus Pos (+) | Orange |
| 7 | Remote OFF | Brown/White |
| 8 | Remote OFF | Brown |



13.0 Programming Requirements

As is the case with other C-Bus units, the DSI Gateway must be programmed to set its unique identification and the mode of operation on the C-Bus Network. The C-Bus Installation Software can be used to configure all operational parameters including the specification of control sources, and power up options. Please refer to the C-Bus Manual for further information relating to the programming of the DSI Gateway unit.

14.0 Power Surges and Short Circuit Conditions

The mains voltage must be limited to the range specified for any unit which is mains powered. Each unit incorporates transient protection circuitry and additional external power surge protection devices can be used to enhance system immunity to power surges. It is strongly recommended over-voltage equipment such as the Clipsal 970 series is installed at the switchboard.

15.0 Megger Testing

Megger testing of the mains powered part of an electrical installation with C-Bus units connected will not cause any damage to C-Bus units. Since C-Bus units contain electronic components, the installer should interpret megger readings with due regard to the nature of the circuit connection.

Megger testing must never be performed on the C-Bus data cabling or on DSI wiring terminals as it may degrade the performance of the network.

16.0 Important Warning

The use of any non C-Bus Software in conjunction with the hardware installation without the written consent of Clipsal Integrated Systems may void any warranties applicable to the hardware.

17.0 Standards Complied


The units have been designed to meet Australian and European standards for EMC Compliance and Safety.

| | |
|---|--|
| AS/NZS 3100:1997 | General Requirements for Electrical Equipment |
| AS/NZS 3108:1994, IEC 742:1983 | Requirements for Safety Extra Low Voltage |
| 97/32C/EE | Low Voltage Directives |
| AS/NZS 1044:1995, IEC/CISPR 14:1993, BS/EN 55014:1994 | RFI Emissions Standard |
| AS/NZS 4051:1998, IEC/CISPR 15:1996, BS/EN 55015:1994 | RFI Emissions Standard |
| IEC669-2-2, BS/EN 60669-2-2 | Particular Requirements for Remote Control Switching Devices |
| BS/EN 61000-4-2 | Immunity to Electrostatic Discharge |
| BS/EN 61000-4-3 | Immunity to Radio Frequency Interference |
| BS/EN 61000-4-4 | Immunity to Electrical Fast Transients |
| BS/EN 61000-4-5 | Immunity to Surge Voltages |
| BS/EN 61000-4-11 | Immunity to Voltage Dips and Interruptions |
| EN 61558 | Safety of Power Supplies and Transformers |
| 89/336/EEC | Electromagnetic Compatibility Directive |

18.0 Product Specifications

| | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|---|---------------------|----------------------|-------------------------|-------------------------|----|-----|--------------------|----------|-----|--------------------|-----|-----|--------------------|--------------------|-------------------|------|---------|------------------|------------|---------|---|-------|------|---------------------------|
| Catalogue Number | 5508DSIP | E5508TDSIP | | | | | | | | | | | | | | | | | | | | | | | | |
| Nominal Supply Voltage | 220 – 240V~ | 110-120V~ | | | | | | | | | | | | | | | | | | | | | | | | |
| Frequency Range(s) | 47 – 53Hz and 57 – 63Hz | | | | | | | | | | | | | | | | | | | | | | | | | |
| C-Bus Supply Voltage | 15-36VDC @ 18mA required for programming when mains power is not connected. 15-36VDC @ 0mA required for programming when mains power is connected. Does not source current to the C-Bus network. | | | | | | | | | | | | | | | | | | | | | | | | | |
| AC Input Impedance | 100k Ω @ 1kHz. A maximum of 100 units can be connected on a single C-Bus network. | | | | | | | | | | | | | | | | | | | | | | | | | |
| Electrical Isolation | 3.75kV RMS. from C-Bus to Mains | | | | | | | | | | | | | | | | | | | | | | | | | |
| Status Indicators | <table border="0"> <tr> <td>C-Bus Status</td> <td><i>Clock Present</i></td> <td><i>No Clock Present</i></td> </tr> <tr> <td>• Voltage \geq 20V DC</td> <td>On</td> <td>Off</td> </tr> <tr> <td>• Voltage < 20V DC</td> <td>Flashing</td> <td>Off</td> </tr> <tr> <td>• Voltage < 15V DC</td> <td>Off</td> <td>Off</td> </tr> <tr> <td>Unit Status</td> <td><i>Mains Power</i></td> <td><i>Conditions</i></td> </tr> <tr> <td>• On</td> <td>Present</td> <td>Normal Operation</td> </tr> <tr> <td>• Flashing</td> <td>Present</td> <td>At least one channel in local or remote override mode</td> </tr> <tr> <td>• Off</td> <td>Fail</td> <td>Mains power not available</td> </tr> </table> <p>Load Indicators (8)</p> <ul style="list-style-type: none"> • On – normal operation and DSI output is at some non-zero C-Bus dimming level. • Off – normal operation and DSI output is at zero C-Bus dimming level. • Flashing, fast rate (8Hz) – DSI channel overloads or output terminals shorted. • Flashing, slow rate (4Hz) – The connected lamp or ballast is faulty. | | C-Bus Status | <i>Clock Present</i> | <i>No Clock Present</i> | • Voltage \geq 20V DC | On | Off | • Voltage < 20V DC | Flashing | Off | • Voltage < 15V DC | Off | Off | Unit Status | <i>Mains Power</i> | <i>Conditions</i> | • On | Present | Normal Operation | • Flashing | Present | At least one channel in local or remote override mode | • Off | Fail | Mains power not available |
| C-Bus Status | <i>Clock Present</i> | <i>No Clock Present</i> | | | | | | | | | | | | | | | | | | | | | | | | |
| • Voltage \geq 20V DC | On | Off | | | | | | | | | | | | | | | | | | | | | | | | |
| • Voltage < 20V DC | Flashing | Off | | | | | | | | | | | | | | | | | | | | | | | | |
| • Voltage < 15V DC | Off | Off | | | | | | | | | | | | | | | | | | | | | | | | |
| Unit Status | <i>Mains Power</i> | <i>Conditions</i> | | | | | | | | | | | | | | | | | | | | | | | | |
| • On | Present | Normal Operation | | | | | | | | | | | | | | | | | | | | | | | | |
| • Flashing | Present | At least one channel in local or remote override mode | | | | | | | | | | | | | | | | | | | | | | | | |
| • Off | Fail | Mains power not available | | | | | | | | | | | | | | | | | | | | | | | | |
| Maximum Number of Units on a single C-Bus Network | 100 | | | | | | | | | | | | | | | | | | | | | | | | | |
| Load Rating | <ul style="list-style-type: none"> • 200mA max. per channel (or 100 DSI ballasts). • 270mA max total. | | | | | | | | | | | | | | | | | | | | | | | | | |
| Interface Type | DSI – Digital Serial Interface | | | | | | | | | | | | | | | | | | | | | | | | | |
| Compatible Loads | TRIDONIC® DSI Dimmable ballast or equivalent (up to 100 per channel) | | | | | | | | | | | | | | | | | | | | | | | | | |
| Channel output voltage | 0.0 – 0.8V (low) to 11.0 – 13.0V (high) | | | | | | | | | | | | | | | | | | | | | | | | | |
| Output control range | 0% to 100%. | | | | | | | | | | | | | | | | | | | | | | | | | |
| Network Clock | Software selectable | | | | | | | | | | | | | | | | | | | | | | | | | |
| Network Burden | Software selectable (Unit address 01 only) | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dimensions | 215 x 85 x 65mm | | | | | | | | | | | | | | | | | | | | | | | | | |
| Remote Override Input | Remote switch input can be daisy chained to maximum of 10 units and a maximum of 1000m of cable. | | | | | | | | | | | | | | | | | | | | | | | | | |
| Mains Terminals | Accommodates 2 x 1.5mm ² or 1 x 2.5mm ² | | | | | | | | | | | | | | | | | | | | | | | | | |
| C-Bus Connection | RJ45 socket | | | | | | | | | | | | | | | | | | | | | | | | | |
| Remote Override Connection | RJ45 socket | | | | | | | | | | | | | | | | | | | | | | | | | |
| Operating Temperature Range | 0 – 45°C | | | | | | | | | | | | | | | | | | | | | | | | | |
| Operating Humidity Range | 10 – 95% RH | | | | | | | | | | | | | | | | | | | | | | | | | |

19.0 Mechanical Specifications



Dimensions in millimeters

Note : No user serviceable parts inside.

20.0 Technical Support and Troubleshooting

For further assistance in using C-Bus Eight Channel 5508DSIP/ E5508TDSIP, please consult your nearest Clipsal Integrated Systems Sales Representative or Technical Support Officer.

Technical Support Email techsupport.cis@clipsal.com.au

Sales Support Email sales.cis@clipsal.com.au

Clipsal Integrated Systems Website

Please visit the Clipsal Integrated Systems Website for information on new product developments, online software registration, software upgrades, plus much more.

Website clipsal.com/cis



Products of Clipsal Integrated Systems Pty Ltd

ACN 089 444 931 ABN 15 089 444 931

Head Office

12 Park Terrace, Bowden
South Australia 5007
PO Box 103 Hindmarsh
South Australia 5007

Telephone (08) 8269 0560
International +61 8 8269 0560
Facsimile (08) 8346 0845
International +61 8 8346 0845
Internet clipsal.com/cis
E-Mail cis@clipsal.com.au

Offices in all States

NSW Sydney (02) 9794 9200
Albury (02) 6041 2377
VIC Melbourne (03) 9207 3200
Country Areas 1800 653 893
QLD Brisbane (07) 3244 7444
Townsville (07) 4729 3333
SA Adelaide (08) 8269 0555
WA Perth (08) 9442 4444
TAS Hobart (03) 6272 3177
Launceston (03) 6343 5900
NT Darwin (08) 8947 0278

International Enquiries

Head Office Export Department

Telephone +61 8 8269 0587
Facsimile +61 8 8340 7350
E-Mail export@clipsal.com.au

International Representatives

New Zealand

Clipsal Industries (NZ) Ltd Auckland
Telephone (09) 576 3403
Facsimile (09) 576 1015
E-Mail headoffice@clipsal.co.nz

Customer Service

Free Fax (0508) 250 305
Auckland/Mobile Phone (09) 572 0014
Free Phone (0508) CLIPSAL
254 7725

Malaysia

Clipsal Integrated Systems Sdn Bhd
Lot 26, Jalan Pengapit 15/19
Shah Alam Industrial Estate
40000 Shah Alam
Selangor Darul Ehsan

West Malaysia

Telephone (3) 5519 1122
Facsimile (3) 5512 3155
E-mail clipsal@clipsaltech.com.my

Singapore

Clipsal Integrated Systems Pte Ltd
No. 5 Fourth Chin Bee Road
Singapore 619699
Telephone (65) 266 1998
Facsimile (65) 266 3922
E-mail clipsal@clipsaltech.com.sg

Argentina

Controles Tecnova S.A. (114) 207 9534

China

Clipsal (China) Ltd (755) 246 1122

Greece

Clipsal Hellas S.A. (1) 600 3718

Middle East

Clipsal Middle East (6) 557 0777

South Africa

Clipsal South Africa (Pty) Ltd (11) 314 5200

Taiwan

Clipsal (Taiwan) Co Ltd (2) 2558 3456

Thailand

Clipsal Thailand Ltd (2) 952 5338

United Kingdom

Clipsal Ltd (UK) (44) 1494 521111

Vietnam

Clipsal – VTEC (8) 856 3002



Intelligent Building Series™

© Copyright 2000 Clipsal Integrated Systems Pty Ltd

1036134